

# MaxO2+

Instructions for Use

SCUBA



**NOTE:** The latest edition of this operating manual can be downloaded from our website at [www.maxtec.com](http://www.maxtec.com)



### Product Disposal Instructions:

The sensor, batteries, and circuit board are not suitable for regular trash disposal. Return sensor to Maxtec for proper disposal or dispose according to local guidelines. Follow local guidelines for disposal of other components.

## CLASSIFICATION

Protection against electric shock:..... Internally powered equipment.  
Protection against water:..... IPX1  
Mode of Operation:..... Continuous  
Sterilization:..... See section 7.0  
Flammable anesthetic mixture: .....Not suitable for use in presence of a  
..... flammable anesthetic mixture

## WARRANTY

Under normal operating conditions, Maxtec warrants the MAX02+ Analyzer to be free from defects of workmanship or materials for a period of 2-years from the date of shipment from Maxtec, provided that the unit is properly operated and maintained in accordance with Maxtec's operating instructions. Based on Maxtec product evaluation, Maxtec's sole obligation under the foregoing warranty is limited to making replacements, repairs, or issuing credit for equipment found to be defective. This warranty extends only to the buyer purchasing the equipment directly from Maxtec or through Maxtec's designated distributors and agents as new equipment.

Maxtec warrants MAX02+ oxygen sensor in the MAX02+ Analyzer to be free from defects in material and workmanship for a period of 2-years from Maxtec's date of shipment in a MAX02+ unit. Should a sensor fail prematurely, the replacement sensor is warranted for the remainder of the original sensor warranty period.

Routine maintenance items, such as batteries, are excluded from warranty. Maxtec and any other subsidiaries shall not be liable to the purchaser or other persons for incidental or consequential damages or equipment that has been subject to abuse, misuse, mis-application, alteration, negligence or accident.

These warranties are exclusive and in lieu of all other warranties, expressed or implied, including warranty of merchantability and fitness for a particular purpose.

## WARNINGS

Indicates a potentially hazardous situation, if not avoided, could result in death or serious injury.

- ◆ Device specified for dry gas only.
- ◆ Before use, all individuals who will be using the MAX02+ must become thoroughly familiar with the information contained in this Operation Manual. Strict adherence to the operating instructions is necessary for safe, effective product performance.
- ◆ This product will perform only as designed if installed and operated in accordance with the manufacturer's operating instructions.
- ◆ Use only genuine Maxtec accessories and replacement parts. Failure to do so may seriously impair the analyzer's performance. Repair of this equipment must be performed by a qualified service technician experienced in repair of portable hand held equipment.
- ◆ Calibrate the MAX02+ weekly when in operation, or if environmental conditions change significantly. (ie, Elevation, Temperature, Pressure, Humidity — refer to Section 3.0 of this manual).
- ◆ Use of the MAX02+ near devices that generate electrical fields may cause erratic readings.
- ◆ If the MAX02+ is ever exposed to liquids (from spills or immersion) or to any other physical abuse, turn the instrument OFF and then ON. This will allow the unit to go through its self test to assure everything is operating correctly.
- ◆ Never autoclave, immerse or expose the MAX02+ (including sensor) to high temperatures (>70°C). Never expose the device to pressure, irradiation vacuum, steam, or chemicals.
- ◆ This device does not contain automatic barometric pressure compensation.

- ◆ Although the sensor of this device has been tested with various gases including nitrous oxide, Halothane, Isoflurane, Enflurane, Sevoflurane and Desflurane and found to have acceptably low interference, the device in entirety (including electronics) is not suitable for use in the presence of a flammable anesthetic mixture with air or with oxygen or nitrous oxide. Only the threaded sensor face, flow diverter, and "T" adapter may be allowed to contact such a gas mixture.
- ◆ NOT for use with inhalation agents. Operating the device in flammable or explosive atmospheres may result in fire or explosion..

## CAUTIONS

















Indicates a potentially hazardous situation, if not avoided, could result in minor or moderate injury and property damage.

- ◆ Replace the batteries with recognized high quality AA Alkaline or Lithium batteries.
- ⊘ **DO NOT** use rechargeable batteries.
- ◆ If the unit is going to be stored (not in use for 1 month), we recommend that you remove the batteries to protect the unit from potential battery leakage.
- ◆ The Maxtec Max-250 oxygen sensor is a sealed device containing a mild acid electrolyte, lead (Pb), and lead acetate. Lead and lead acetate are hazardous waste constituents and should be disposed of properly, or returned to Maxtec for proper disposal or recovery.
- ⊘ **DO NOT** use ethylene oxide sterilization.
- ⊘ **DO NOT** immerse the sensor in any cleaning solution, autoclave or expose the sensor to high temperatures.
- ◆ Dropping sensor can adversely affect its performance.
- ◆ The device will assume a percent oxygen concentration when calibrating. Be sure to apply 100% oxygen, or ambient air concentration to the device during calibration or the device will not calibrate correctly.

**NOTE:** This product is latex free.

## SYMBOL GUIDE

The following symbols and safety labels are found on the Max02+:

	Follow instructions for use		On/Off Button
	Warning		Calibration Button
	Meets ETL standards		Do not throw away. Follow local guidelines for disposal
	DO NOT		Percent
	Low Battery		Serial Number
	Calibration Required		Lot code/Batch code
	Caution		Ingress Protection Rating
	Catalog Number		Manufacturer

# 1.0 OVERVIEW

## 1.1 Base Unit Description

- The MAXO2+ analyzer provides unparalleled performance and reliability due to an advanced design that includes the following features and operational benefits.
- Extra-life oxygen sensor of approximately 1,500,000 O2 percent hours (2-year warranty)
- Durable, compact design that permits comfortable, hand-held operation and easy to clean
- Operation using only two AA Alkaline batteries (2 x 1.5 Volts) for approximately 5000 hours of performance with continuous use. For extra extended long life, two AA Lithium batteries may be used.
- Oxygen-specific, galvanic sensor that achieves 90% of final value in approximately 15 seconds at room temperature.
- Large, easy-to-read, 3 1/2-digit LCD display for readings in the 0-100% range.
- Simple operation and easy one-key calibration.
- Self-diagnostic check of analog and microprocessor circuitry.
- Low battery indication.
- Calibration reminder timer that alerts the operator, using a calibration icon on the LCD display, to perform a unit calibration.

## 1.2 Component Identification




FIGURE 1

- 1 **3-DIGIT LCD DISPLAY** — The 3 digit liquid crystal display (LCD) provides direct readout of oxygen concentrations in the range of 0 – 105.0% (100.1% to 105.0% used for calibration determination purposes). The digits also display error codes and calibration codes as necessary.
- 2 **LOW BATTERY INDICATOR** — The low battery indicator is located at the top of the display and is only activated when the voltage on the batteries is below a normal operating level.
- 3 **“%” SYMBOL** — The “%” sign is located to the right of the concentration number and is present during normal operation.
- 4 **CALIBRATION SYMBOL** — The calibration symbol is located at the bottom of the display and is timed to activate when a calibration is necessary.
- 5 **ON/OFF KEY** — This key is used to turn the device on or off.
- 6 **CALIBRATION KEY** — This key is used to calibrate the device. Holding the key for more than three seconds will force the device to enter a calibration mode.
- 7 **SAMPLE INLET CONNECTION** — This is the port at which the device is connected to determine oxygen concentration.

# 2.0 OPERATING INSTRUCTIONS

## 2.1 Getting Started

### 2.1.1 Protect Tape

Prior to turning on the unit, a protective film covering the threaded sensor face must be removed. After removing the film, wait approximately 20 minutes for the sensor to reach equilibrium.

### 2.1.2 Automatic Calibration

After the unit is turned on it will automatically calibrate to room air. The display should be stable and reading 20.9%.

**CAUTION:** The device will assume a percent oxygen concentration when calibrating. Be sure to apply 100% oxygen, or ambient air concentration to the device during calibration or the device will not calibrate correctly.

To check the oxygen concentration of a sample gas: (after the unit has been calibrated):

1. Connect the Tygon tubing to the bottom of the analyzer by threading the barbed adapter onto the oxygen sensor. (FIGURE 2)
2. Attach the other end of the sample hose to the sample gas source and initiate flow of the sample to the unit at a rate of 1-10 liters per minute (2 liters per minute is recommended).
3. Using the “ON/OFF” key, make sure the unit is in the power “ON” mode.
4. Allow the oxygen reading to stabilize. This will normally take about 30 seconds or more..




FIGURE 2

## 2.2 Calibrating the MAXO2+ Oxygen Analyzer

**NOTE:** We recommend use of medical grade USP or >99% purity oxygen when calibrating the MAXO2+.

The MAXO2+ Analyzer should be calibrated upon initial power-up. Thereafter, Mextec recommends calibration on a weekly basis. To serve as a reminder, a one week timer is started with each new calibration. At the end of one week a reminder icon “” will appear on the bottom of the LCD. Calibration is recommended if the user is unsure when the last calibration procedure was performed, or if the measurement value is in question. Start calibration by pressing the Calibration key for more than 3 seconds. The MAXO2+ will automatically detect if you are calibrating with 100% oxygen or 20.9% oxygen (normal air).

**DO NOT** attempt to calibrate to any other concentration.



**For ID testing, (or optimum accuracy) a new calibration is required when:**

- The measured O2 percentage in 100% O2 is below 99.0% O2.
- The measured O2 percentage in 100% O2 is above 101.0% O2.
- The CAL reminder Icon is blinking at the bottom of the LCD.
- If you are unsure about the displayed O2 percentage (See Factors influencing accurate readings).

A simple calibration may be made with the sensor open to static at Ambient air. For optimum accuracy Mextec recommends that the Sensor be placed in a closed loop circuit where gas flow is moving across the sensor in a controlled manner. Calibrate with the same type of circuit and flow that you will use in taking your readings.

### 2.2.1 Direct Flow Calibration (Barb)

1. Attach the Barbed Adapter to the MAXO2+ by threading it on to the bottom of the sensor.
2. Connect the Tygon tube to the barbed adapter. (FIGURE 2)

3. Attach the other end of the clear sampling tube to a source of oxygen with a known oxygen concentration value. Initiate flow of the calibration gas to the unit. Two liters per minute is recommended.
4. Allow the oxygen to saturate the sensor. Although a stable value is usually observed within 30 seconds, allow at least two minutes to ensure that the sensor is completely saturated with the calibration gas.
5. If the MAXO2+ is not already turned on, do so now by pressing the analyzer "ON"  button.
6. Press the Cal  button on the MAXO2+ until you read the word CAL on the analyzer display. This can take approximately 3 seconds. The analyzer will now look for a stable sensor signal and a good reading. When obtained, the analyzer will display the calibration gas on the LCD.

### 2.3 Operation with Oxyknob Adapter

1. Attach the Oxyknob adaptor to the threaded sensor of your Maxtec Analyzer.
2. Hand tighten until sensor o-ring seals against the Oxyknob.
3. Slowly crack open the tank. Listen for a slight hissing sound.
4. Hold the Oxyknob up to the outlet of the tank.
5. Align the small hole in the bottom or side of the Oxyknob to the hole in the outlet of the tank.
6. Hold the analyzer in place until the reading has stabilized on the analyzer display. (about 15 seconds or less)
7. Remove Oxyknob after reading and close valve on the tank.




FIGURE 3

**⚠ WARNING:** High gas pressures may cause damage to oxygen sensor and result in incorrect readings. Turn down the tank valve as much as possible to avoid sensor damage.

**⊘ DO NOT** cover the larger holes on the Oxyknob.

Cold gas exiting a pressurized tank can cause the sensor reading to drift if exposed for an extended period of time. Allow sensor to warm between readings if necessary.

### 2.4 Operation with Optional BC Adapter

1. Attach the included Barbed Adapter to the MAXO2+ by threading it on to the bottom of the sensor.
2. Connect the included tubing to the barbed adapter.
3. Attach the BC adapter (sold separately) to the other end of the tube.
4. Connect the inflator hose on the regulator to the BC adapter and tube.
5. If the MAXO2+ is not already turned on, do so now by pressing the analyzer "ON" button.
6. Initiate flow of nitrox to the unit to allow the gas to saturate the sensor. The BC adapter will regulate the optimum flow and pressure. Although a stable value is usually observed within 30 seconds, allow at least two minutes to ensure that the sensor is completely saturated with the gas.
7. The analyzer will now look for a stable sensor signal and a good reading. When obtained, the analyzer will display the oxygen percentage on the LCD.




FIGURE 4

## 3.0 FACTORS INFLUENCING ACCURATE READINGS

### 3.1 Elevation/Pressure Changes

1. Changes in elevation result in a reading error of approximately 1% of reading per 250 feet.
2. In general, calibration of the instrument should be performed when elevation at which the product is being used changes by more than 500 feet.
3. This device does not automatically compensate for changes in barometric pressure or altitude. If the device is moved to a location of a different altitude, it must be recalibrated before use.

### 3.2 Temperature Effects

The MAXO2+ will hold calibration and read correctly within  $\pm 3\%$  when at thermal equilibrium within the operating temperature range. The device must be thermally stable when calibrated and allowed to thermally stabilize after experiencing temperature changes before readings are accurate. For these reasons, the following is recommended:

- For best results, perform the calibration procedure at a temperature close to the temperature where analysis will occur.
- Allow adequate time for the sensor to equilibrate to a new ambient temperature.

**CAUTION:** "CAL Err St" may result from a sensor that has not reached thermal equilibrium.

### 3.3 Pressure Effects

Readings from the MAXO2+ are proportional to the partial pressure of oxygen. The partial pressure is equal to the concentration times the absolute pressure.

Thus, the readings are proportional to the concentration if the pressure is held constant. Therefore, the following are recommended:

- Calibrate the MAXO2+ at the same pressure as the sample gas.
- If sample gases flow through tubing, use the same apparatus and flow rates when calibrating as when measuring.

### 3.4 Humidity Effects

Humidity (non-condensing) has no effect on the performance of the MAXO2+ other than diluting the gas, as long as there is no condensation. Depending on the humidity, the gas may be diluted by as much as 4%, which proportionally reduces the oxygen concentration. The device responds to the actual oxygen concentration rather than the dry concentration. Environments where condensation may occur are to be avoided since moisture may obstruct passage of gas to the sensing surface, resulting in erroneous readings and slower response time. For this reason, the following is recommended:

- Avoid usage in environments greater than 95% relative humidity.

**HELPFUL HINT:** Dry sensor by lightly shaking moisture out, or flow a dry gas at two liters per minute across the sensor membrane

## 4.0 CALIBRATION ERRORS AND ERROR CODES

The MAXO2+ analyzers have a self test feature built into the software to detect faulty calibrations, oxygen sensor failures, and low operating voltage. These are listed below, and include possible actions to take, if an error code occurs.

**E02:** No sensor attached

- MaxO2+A: Open unit and disconnect and reconnect sensor. Unit should perform an auto calibration and should read 20.9%. If not, contact Maxtec Customer Service for possible sensor replacement.
- MaxO2+AE: Disconnect and reconnect external sensor. Unit should perform an auto calibration, and should read 20.9%. If not, contact Maxtec Customer Service for possible sensor replacement or cable replacement.

**MAXO2+AE:** Disconnect and reconnect external sensor. Unit should perform an auto calibration, and should read 20.9%. If not, contact Maxtec Customer Service for possible sensor replacement or cable replacement.

**E03:** No valid calibration data available

- Make sure unit has reached thermal equilibrium. Press and hold the Calibration Button for three seconds to manually force a new calibration.

#### **E04:** Battery below minimum operating voltage

- Replace batteries.

#### **CAL ERR ST:** O2 Sensor reading not stable

- Wait for displayed oxygen reading to stabilize, when calibrating the device at 100% oxygen.
- Wait for unit to reach thermal equilibrium, (Please note that this can take up to one half hour, if the device is stored in temperatures outside the specified operating temperature range).

#### **CAL ERR LO:** Sensor voltage too low

- Press and hold the Calibration Button for three seconds to manually force a new calibration. If unit repeats this error more than three times, contact Maxtec Customer Service for possible sensor replacement.

#### **CAL ERR HI:** Sensor voltage too high

- Press and hold the Calibration Button for three seconds to manually force a new calibration. If unit repeats this error more than three times, contact Maxtec Customer Service for possible sensor replacement.

#### **CAL ERR BAT:** Battery voltage too low to recalibrate

- Replace batteries.

## 5.0 CHANGING THE BATTERIES

Batteries should be changed by service personnel.

- Use only brand name batteries.
- Replace with two AA batteries and insert per orientation marked on the device.

Should the batteries require changing, the device will indicate this in one of two ways:

- The battery icon on the bottom of the display will begin to flash. This icon will continue to flash until the batteries are changed. The unit will continue to function normally for approx. 200 hours.
- If the device detects a very low battery level, an error code of “E04” will be present on the display, and the unit will not function until the batteries are changed.




FIGURE 5

To change the batteries, begin by removing the three screws from the back of the device. A #1 Phillips screwdriver is required to remove these screws. Once the screws are removed, gently separate the two halves of the device.

The batteries can now be replaced from the back half of the case. Be sure to orient the new batteries as indicated in the embossed polarity on the back case.

**NOTE:** If the batteries are installed incorrectly the batteries will not make contact and the device will not operate.

Carefully, bring the two halves of the case together while positioning the wires so they are not pinched between the two case halves. The gasket separating the halves will be captured on the back case half.

Reinsert the three screws and tighten until the screws are snug. (FIGURE 3)

The device will automatically perform a calibration and begin displaying % of oxygen.

**HELPFUL HINT:** If unit does not function, verify that the screws are tight to allow proper electrical connection.

**HELPFUL HINT:** Before closing the two case halves together, verify that the keyed slot on top of the coiled cable assembly is engaged on the small tab located on the back case. This is designed to position the assembly in the correct orientation and prevent it from rotating.

Improper positioning could hinder the case halves from closing and prevent operation when tightening the screws.

## 6.0 CHANGING THE OXYGEN SENSOR

### 6.1 MaxO2+A Model

Should the oxygen sensor require changing, the device will indicate this by presenting “Cal Err lo” on the display after initiating a calibration.

To change the oxygen sensor, begin by removing the three screws from the back of the device.

A #1 Phillips screwdriver is required to remove these screws.

Once the screws are removed, gently separate the two halves of the device.




FIGURE 6

Disconnect the oxygen sensor from the printed circuit board by pressing the unlock lever first and then pulling the connector out of the receptacle. The oxygen sensor can now be replaced from the back half of the case.

**HELPFUL HINT:** Be sure to orient the new sensor by aligning the red arrow on the sensor with the arrow in the back case. A small tab is located on the back case that is designed to engage the sensor and prevent it from rotating within the case. (FIGURE 3)

**NOTE:** If the oxygen sensor is installed incorrectly, the case will not come back together and the unit may be damaged when the screws are reinstalled.

**NOTE:** If the new sensor has red tape over the outside, remove it, then wait 30 minutes before calibrating.

Reconnect the oxygen sensor to the connector on the printed circuit board. Carefully bring the two halves of the case together while positioning the wires to ensure they are not pinched between the two case halves. Make sure the sensor is fully inserted and in the proper orientation.

Reinsert the three screws and tighten until the screws are snug. Verify the unit operates properly. The device will automatically perform a calibration and begin displaying % of oxygen.

### 6.2 MaxO2+AE Model

Should the oxygen sensor require changing, the device will indicate this by presenting “Cal Err lo” on the display.

Unthread the sensor from the cable by rotating the thumbscrew connector counterclockwise and pull the sensor from the connection. Replace the new sensor by inserting the electrical plug from the coiled cord into the receptacle on the oxygen sensor. Rotate the thumbscrew clockwise until snug. The device will automatically perform a calibration and begin displaying % of oxygen.

## 7.0 CLEANING AND MAINTENANCE

Store the MAXO2+ analyzer in a temperature similar to its ambient environment of daily use.

The instruction given below describes the methods to clean and disinfect the instrument, sensor and its accessories (e.g. flow diverter, tee adapter):

### Instrument Cleaning:

◆ When cleaning or disinfecting the exterior of the MAXO2+ analyzer, take appropriate care to prevent any solution from entering the instrument.

⊘ **DO NOT** immerse unit in fluids.

◆ The MAXO2+ analyzer surface may be cleaned using a mild detergent and a moist cloth.

◆ The MAXO2+ analyzer is not intended for steam, ethylene oxide or radiation sterilization..

### Oxygen Sensor:



**WARNING:** Never install the sensor in a location that will expose the sensor to patient's exhaled breath or secretions, unless you intend to dispose of the sensor, flow diverter and tee adapter after use.

- ◆ Clean the sensor with a cloth moistened with isopropyl alcohol (65% alcohol/water solution).
- ◆ Maxtec does not recommend use of spray disinfectants because they can contain salts, which can accumulate in the sensor membrane and impair readings.
- ◆ The oxygen sensor is not intended for steam, ethylene oxide or radiation sterilization.

**Accessories:**

The flow diverter and tee adapter may be disinfected by washing them with isopropyl alcohol. The parts must be thoroughly dry before they are used

**8.0 SPECIFICATIONS**

**8.1 Base Unit Specifications**

Measurement Range:.....0-100%  
 Resolution:.....0.1%  
 Accuracy and Linearity: .....1% of full scale at constant temperature, R.H. and .....pressure when calibrated at full scale  
 Total Accuracy:.....±3% actual oxygen level over full operating temp range  
 Response Time: .....90% of final value in approximately 15 seconds at 23 °C  
 Warm-up Time: .....None required  
 Operating Temperature:.....15 °C - 40 °C (59 °F - 104 °F)  
 Storage Temperature:.....-15 °C - 50 °C (5 °F - 122 °F)  
 Atmospheric Pressure:.....800-1013 mBars  
 Humidity: .....0-95% (non-condensing)  
 Power Requirements:.....2, AA Alkaline batteries (2 x 1.5 Volts)  
 Battery Life:.....approximately 5000 hours with continuous use  
 Low Battery Indication: ..... "BAT" icon displayed on LCD  
 Sensor Type:.....Maxtec MAX-250 series galvanic fuel cell  
 Expected Sensor Life:..... > 1,500,000 O2 percent hours minimum  
 .....(2-year in typical medical applications)  
 Dimensions: .....  
 A Model Dimensions: .....3.0"(W) x 4.0"(H) x 1.5"(D) [76mm x 102mm x 38mm]  
 A Weight:.....0.4 lbs. (170g)  
 AE Model Dimensions: .....3.0"(W) x 36.0"(H) x 1.5"(D) [76mm x 914mm x38mm]  
 .....Height includes external cable length (retracted)  
 AE Weight:.....0.6 lbs. (285g)  
 Drift of Measurement:..... < +/-1% of full scale at constant temperature,  
 .....pressure and humidity)

**8.2 Sensor Specifications**

Type: .....Galvanic fuel sensor (0-100%)  
 Life: .....2-years in typical applications

**9.0 MAXO2+ SPARE PARTS AND ACCESSORIES**

**9.1 Included With Your Unit**

PART NUMBER	ITEM	A MODEL	AE MODEL
R217M42	User's Guide and Operating Instructions	X	X
RP76P06	Lanyard	X	X
R110P10-001	Flow Diverter	X	X

**9.2 Standard Replacement Parts and Accessories**

PART NUMBER	ITEM	A MODEL	AE MODEL
R125P02-011	Max-250+ Oxygen Sensor	X	
R125P03-002	Max-250E Oxygen Sensor		X
R115P85	Max-250ESF Oxygen Sensor		X
RZ17P08	Gasket	X	X
RP06P25	#4-40 Pan Head Stainless Steel Screw	X	X
RZ17P16-001	Front Assembly (Includes Board & LCD)	X	X
RZ17P11-002	Back Assembly	X	X
RZ17P24	Coiled Cable Assembly		X
RZ17P09-001	Overlay	X	X

**9.3 Optional Accessories**

**9.3.1 Optional Adapters**

PART NUMBER	ITEM
RP16P02	Blue Tee Adapter
R103P90	Perfusion Tee Adapter
RP16P12	Long-Neck Tee Adapter
RP16P05	Pediatric Tee Adapter
RP16P10	MAX-Quick Connect
RZ07P17	Threaded Adapter with Tygon Tubing

**9.3.2 Mounting Options (requires dovetail R217P23)**

PART NUMBER	ITEM
RZ06P75	Pole Mount
RZ05P86	Wall Mount
R100P10	Rail Mount
RZ13P31	Swivel Mount

**9.3.3 Carrying Options**

PART NUMBER	ITEM
RZ17P22	Belt Clip and Pin
RZ13P02	Zipper Carrying Case with Shoulder Strap
RZ13P56	Deluxe Carrying Case, Water Tight
RZ17P32	Soft Case, Tight Fit Carrying Case

**NOTE:** Repair of this equipment must be performed by a qualified service technician experienced in repair of portable hand held medical equipment.

Equipment in need of repair shall be sent to:

Maxtec, Service Department, 2305 South 1070 West, Salt Lake City, Ut 84119  
 (Include RMA number issued by customer service)

**10.0 ELECTROMAGNETIC COMPATIBILITY**

The information contained in this section (such as separation distances) is in general specifically written with regard to the MaxO2+ A/AE. The numbers provided will not guarantee faultless operation but should provide reasonable assurance of such. This information may not be applicable to other medical electrical equipment; older equipment may be particularly susceptible to interference.

Note: Medical electrical equipment requires special precautions regarding electromagnetic compatibility (EMC) and needs to be installed and put into service according to the EMC information provided in this document and the remainder of the instructions for use this device.

Portable and mobile RF communications equipment can affect medical electrical equipment.

Cables and accessories not specified within the instructions for use are not authorized. Using other cables and/or accessories may adversely impact safety, performance and electromagnetic compatibility (increased emission and decreased immunity).

Care should be taken if the equipment is used adjacent to or stacked with other equipment; if adjacent or stacked use is inevitable, the equipment should be observed to verify normal operation in the configuration in which it will be used.

ELECTROMAGNETIC EMISSIONS		
This equipment is intended for use in the electromagnetic environment specified below. The user of this equipment should assure that it is used in such an environment.		
EMISSIONS	COMPLIANCE ACCORDING TO	ELECTROMAGNETIC ENVIRONMENT
RF Emissions (CISPR 11)	Group 1	The Max02+ uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment.
CISPR Emissions Classification	Class A	The Max02+ is suitable for use in all establishments other than domestic and those directly connected to the public low-voltage power supply network that supplies buildings used for domestic purposes.  <b>NOTE:</b> The EMISSIONS characteristics of this equipment make it suitable for use in industrial areas and hospitals (CISPR 11 class A). If it is used in a residential environment (for which CISPR 11 class B is normally required) this equipment might not offer adequate protection to radio-frequency communication services. The user might need to take mitigation measures, such as relocating or re-orienting the equipment.
Harmonic Emissions (IEC 61000-3-2)	Class A	
Voltage Fluctuations	Complies	

Recommended separation distances between portable and mobile RF communications equipment and the equipment			
RATED MAXIMUM OUTPUT POWER OF TRANSMITTER W	Separation distance according to frequency of transmitters in meters		
	150 kHz to 80 MHz $d=1.2/\sqrt{P}$	80 MHz to 800 MHz $d=1.2/\sqrt{P}$	800MHz to 2.5 GHz $d=2.3 \sqrt{P}$
0.01	0.12	0.12	0.23
0.1	0.38	0.38	0.73
1	1.2	1.2	2.3
10	3.8	3.8	7.3
100	12	12	23


For transmitters rated at a maximum output power not listed above, the recommended separation distance *d* in meters (m) can be estimated using the equation applicable to the frequency of the transmitter, where *P* is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer.

**NOTE 1:** At 80 MHz and 800 MHz, the separation distance for the higher frequency range applies.

**NOTE 2:** These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects, and people.

ELECTROMAGNETIC IMMUNITY		
This equipment is intended for use in the electromagnetic environment specified below. The user of this equipment should assure that it is used in such an environment.		
IMMUNITY AGAINST	IEC 60601-1-2: (4TH EDITION) TEST LEVEL	
	Professional Healthcare Facility Environment	Home Healthcare Environment
ELECTROMAGNETIC ENVIRONMENT		

Electrostatic discharge, ESD (IEC 61000-4-2)	Contact discharge: ±8 kV Air discharge: ±2 kV, ±4 kV, ±8 kV, ±15 kV	Floors should be wood, concrete, or ceramic tile. If floors are covered with synthetic material, the relative humidity should be kept at levels to reduce electrostatic charge to suitable levels.
Electrical fast transients / bursts (IEC 61000-4-4)	Power supply lines: ±2 kV Longer input / output lines: ±1 kV	
Surges on AC mains lines (IEC 61000-4-5)	Common mode: ±2 kV Differential mode: ±1 kV	Mains power quality should be that of a typical commercial or hospital environment.
3 A/m power frequency magnetic field 50/60 Hz (IEC 61000-4-8)	30 A/m 50 Hz or 60 Hz	Equipment which emits high levels of power line magnetic fields (in excess of 30A/m) should be kept at a distance to reduce the likelihood of interference.
Voltage dips and short interruptions on AC mains input lines (IEC 61000-4-11)	Dip >95%, 0.5 periods Dip 60%, 5 periods Dip 30%, 25 periods Dip >95%, 5 seconds	If user requires continued operation during power mains interruptions, ensure that batteries are installed and charged. Ensure that battery life exceeds longest anticipated power outages or provide an additional uninterruptible power source.

This equipment is intended for use in the electromagnetic environment specified below. The customer or the user of this equipment should assure that it is used in such an environment.			
IMMUNITY TEST	IEC 60601-1-2: 2014 (4TH EDITION) TEST LEVEL		ELECTROMAGNETIC ENVIRONMENT - GUIDANCE
	Professional Healthcare Facility Environment	Home Healthcare Environment	
Conducted RF coupled into lines (IEC 61000-4-6)	3V (0.15 - 80 MHz) 6V (ISM bands)	3V (0.15 - 80 MHz) 6V (ISM & Amateur bands)	Portable and mobile RF communications equipment (including cables) should be used no closer to any part of the equipment than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter as below.  <b>Recommended separation distance:</b> $d=1.2 \sqrt{P}$ $d=1.2 \sqrt{P}$ 80 MHz to 800 MHz $d=2.3 \sqrt{P}$ 800 MHz to 2.7 GHz
Radiated RF immunity (IEC 61000-4-3)	3 V/m 80 MHz - 2.7 GHz 80% @ 1 KHz AM Modulation	10 V/m 80 MHz - 2.7 GHz 80% @ 1 KHz AM Modulation	Where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer and d is the recommended separation distance in metres (m).  Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey a, should be less than the compliance level in each frequency range b.  Interference may occur in the vicinity of equipment marked with the following symbol: 

The ISM (industrial, scientific and medical) bands between 150 kHz and 80 MHz are 6,765 MHz to 6,795 MHz; 13,553 MHz to 13,567 MHz; 26,957 MHz to 27,283 MHz; and 40,66 MHz to 40,70 MHz.

Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radio, AM and FM radio broadcast and TV broadcast cannot be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the equipment is used exceeds the applicable RF compliance level above, the equipment should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as reorienting or relocating the equipment.



2305 South 1070 West  
Salt Lake City, Utah 84119  
(800) 748-5355  
[www.maxtec.com](http://www.maxtec.com)